COOKTOP, BURNER AND GRATE PARTS

For Models: GLT3615LB02, GLT3615LQ02, GLT3615LT02

(Black) (White) (Biscuit)

36" GAS GLASS SURFACE COOKTOP



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP, BURNER AND GRATE PARTS

For Models: GLT3615LB02, GLT3615LQ02, GLT3615LT02
(Black) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		LITERATURE PARTS
	LIT4455834	Installation Instructions
	LIT8285326	Use & Care Guide
	LIT3192099	Wiring Diagram
	LIT3191638	Safe Cooking Tips
	LIT3192742	L.P. Conversion Instructions
2		Grommet, Glass
	3180081	White
	3180079	Black
	3191817	Biscuit
3		Bowl, Burner (LF)(LR)(RR)
	3191303	White
	3191302	Black
	3191818	Biscuit
4		Bowl, Burner (RF)(Center)
	3191307	Black
	3191308	White
	3191819	Biscuit
6		Cap, Burner 6K (RF)(Center)
	3191898	Black
	3191899	Mouse Gray
	8273343	Espresso
7		Cooktop, Glass
	8285094	White
	8285093	Black
	8285095	Biscuit
8		Cap, Burner 9K (RR)(LR)
	3191901	Black
	3191903	Mouse Gray
	8273344	Espresso
9		Cap, Burner 12K (LF)
	3191904	Black
	3191905	Mouse Gray
	8273345	Espresso
10		Grate, Burner
	4456213	Mouse Gray
	4456212	Black
	4456214	Espresso
12		Knob, Control (4)
	8285071	White
	8285069	Black
	8285070	Biscuit
15		Holder, Orifice
	4456619	Rapide
	4456620	Semi Rapide
	4456621	Auxi
16		Head, Burner
	4455979	RF − Center
	4455980	RR − LR
	4455981	LF
20	3368921	Screw

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: GLT3615LB02, GLT3615LQ02, GLT3615LT02

(Black) (White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BURNER BOX, GAS VALVES, AND SWITCHES

For Models: GLT3615LB02, GLT3615LQ02, GLT3615LT02
(Black) (White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	3191557	Rail, Burner
2	6610013	Pipe, Manifold
3	4456816	Valve, Gas Burner (RF) − (Center)
4	3191387	Seal, Shaft
5	4456817	Valve, Gas Burner (RR)(LR)(LF)
6	3192491	Bracket, Manifold
7	3192819	Rail, Center
8	3185829	Bolt, Gas Valve
9	3177991	Screw
12	4456901	Harness & Switches
14	3191324	Tubing, Gas Burner (RF)
15	3191326	Tubing, Gas Burner (LF)
16	3191325	Tubing, Gas Burner (RR)
17	3191327	Tubing, Gas Burner (LR)
18	3191332	Tubing, Gas Burner (Center)
20	3191462	Shield, Heat
21	3177120	Regulator, Pressure
22	4456784	Burner Box
	4449809	Screw
27	8522424	Module Spark
	3400843	Screw
28	4455917	Bracket, Mounting

PARTS NOT ILLUSTRATED

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated

3192231	Cord, Power
4173634	Bushing
3177991	Screw
4455917	Bracket
4167077	Tinnerman Nut
3191933	Seal, Foam−Cooktop

Miscellaneous

4455918	Hardware, Mounting
3192741	Conversion Kit Natural Gas To L.P.

WIRING HARNESS PARTS

4456626	Harness, Ignitor 15" (2)
4456627	Harness, Ignitor 28" (2)
8285402	Wire, Ground